



- 1 PROVIDE 1" x 1" STAINLESS STEEL SCREEN OVER END OF DUCT OPENING AND SECURE IN PLACE ON ALL SIDES.
- 2 INSTALL DUCTWORK THROUGHOUT THIS AREA OF THE BUILDING UP IN BETWEEN EXISTING BAR JOIST AND THROUGH JOIST WEBBING, UNLESS OTHERWISE NOTED.
- 3 REFER TO SECTION 'A' SHOWN ON DWG. H-E1 FOR REQUIRED DUCTWORK MODIFICATIONS.
- 4 REFER TO SECTION 'C' SHOWN ON DWG. H-E2 FOR REQUIRED DUCTWORK MODIFICATIONS.

