



1. CONNECT TO EXISTING DOMESTIC COLD AND HOT WATER PIPING AT THIS APPROXIMATE LOCATION. FURNISH AND INSTALL NEW PIPE HANGERS FOR NEW PIPING AS NECESSARY. FURNISH AND INSTALL NEW PIPE INSULATION ON DOMESTIC WATER PIPING AND ANY EXISTING PIPE THAT THE INSULATION WAS REMOVED TO PERFORM WORK. FURNISH AND INSTALL SHUT-OFF VALVES AT BRANCH CONNECTIONS.
2. FURNISH AND INSTALL NEW 1/2" COLD WATER PIPING TO EXISTING BLOCK WALL.
3. CONNECT NEW 2" SANITARY VENT PIPING TO EXISTING SANITARY VENT PIPING IN EXISTING CHASE. SEE SANITARY RISER DIAGRAMS FOR CONNECTION LOCATION.
4. FURNISH AND INSTALL NEW 1/2" COLD WATER PIPING TO EXISTING CONNECTIONS AND PROVIDE LINE SIZE PIPE CAP ON DOMESTIC COLD AND HOT WATER PIPING IN CHASE. PATCH AND REPAIR WALL TO MATCH EXISTING CONDITIONS.
5. CONNECT TO EXISTING 1/2" COLD HOT WATER PIPING AT THIS APPROXIMATE LOCATION. FURNISH AND INSTALL NEW PIPE HANGERS FOR NEW PIPING AS NECESSARY. FURNISH AND INSTALL NEW PIPE INSULATION ON DOMESTIC WATER PIPING AND ANY EXISTING PIPE THAT THE INSULATION WAS REMOVED TO PERFORM WORK.
6. FURNISH AND INSTALL NEW 1" COLD WATER BRANCH CONNECTION ON EXISTING 1" DOMESTIC COLD WATER PIPING. FURNISH AND INSTALL NEW PIPE HANGERS FOR NEW PIPING AS NECESSARY. FURNISH AND INSTALL NEW SHUT-OFF BALL VALVES AT BRANCH CONNECTIONS. FURNISH AND INSTALL NEW PIPE INSULATION ON DOMESTIC WATER PIPING AND ANY EXISTING PIPE THAT THE INSULATION WAS REMOVED TO PERFORM WORK.